


3" Wide Furring Strips  
Made from 7/16" OSB board

Attach directly to the wall spaced  
16" apart from center to center of strip

16"



Attach planks to  
furring strips as  
desired.

